

## Steps for Renovating/Remodeling

- **Assess** the seriousness of the problem (eyes, ears, nose),
- **Screen** seriousness of problem (do-it-yourself kits or **NORMI™** Certified Mold Inspector third party consultation),
- **Remediate** those specific areas where serious health effects might result,
- **Protect** yourself with N-95 mask and gloves,
- **Remove** all damaged construction materials that appear unsalvageable (drywall should be removed half again as high as visible mold),
- **Spray** affected structural members with a anti-microbial, NOT bleach. Become a label-reader or use a **NORMI™** approved mold cleaner.
- **Dehumidify and Oxidize** at “drywall stage” for 3-5 days to destroy remaining contaminants,
- **Protect** construction structure surfaces with **NORMI™** approved protectant for long-lasting results.
- **Rebuild** using the “Mold-Free Construction” process to rebuild the structure the right way (controlling all aspects of potential moisture intrusion).
- **Clearance screening** and **NORMI™** Sanitization Protocol” to follow renovation will give proven results.